



# 使用说明





---


上盖



1. 确认打印机电源开关处于关闭（O）状态。
2. 将电源线连接到打印机。
3. 将电源线另一端连接到附近的插座。

1

A technical line drawing of the rear panel of a printer. The drawing shows various ports and components. A circled number '1' is positioned to the left of the panel, with a line pointing to a small rectangular switch on the rear panel, which is the power switch mentioned in the instructions.





# 合格证

---

---