



USER'S MANUAL


No.9921 碎纸机使用说明书

MODEL:S220LPS3-1



使用时注意事项	1
产品规格	2
装箱清单	2
产品外形结构及名称	3
使用说明	3
保养方法	4
常见故障分析及排除	4
Useage attention	5
Product Specifications	6
Packing List	6
Product Outlook & Names	7
Operating Procedures	7
Maintenance	8
Trouble Analysis & Troubleshooting	8






产品外形结构及名称

拉 手


使用说明

保



Please the shredder in

✘



Proc

Ope

Maintenance

Trouble Analysis & Troubleshooting

TROUBLE	TROUBLE ANALYSIS	TROUBLESHOOTING
SHREDDER NO RUNNING		
CONSTANTLY RUNNING		
NOISE LOUD		

In case the above operations are not able to remove any trouble of the shredder, please stop using it immediately, disconnect the power plug and switch off power supply. Contact the local service agency.

团有限

GROUP C

海县黄

s Sto

gl

扶

Www.en-stationery.c